



## How to operate TOUCH SENSOR Ambient Touch Mirror

### 1.) On/Off

To turn on/ off the mirror, briefly touch the sensor switch (marked ring on the mirror surface). The Touch switch is illuminated only when mirror light is off and off when mirror light is on. When Ambient Touch mirror is connected to a wall switch – this needs to be on to operate the mirror.

### 2.) DIM:

To change the lighting intensity DIM:

1. Turn on the mirror (with one short touch)
2. Press immediately again and hold the switch for a short while (about 2 seconds) and release
3. Hold the switch down longer and the lighting intensity will change
4. When the desired light intensity is reached, release the switch

### 3.) Colour

Change color stepless from 3000K-6000K which is experienced from warmer to cooler color light by:

1. Turn on the mirror (with one short touch)
2. Hold the switch longer and the colour temperature will change
3. When the desired colour is reached, release the switch

### 4.) Memory:

The switch has a memory of the last lighting state on, color and intensity. The function works even in the event of a power outage in the network supplying the mirror.

## Hur man använder TOUCH SENSOR Ambient Touch Spegel

### 1.) Av/På

För att tända/ släcka spegeln tryck på sensor-markering en gång och släpp direkt (rund ring på spegelns yta). Touch sensorn är belyst endast när spegelns belysning är av och släcks när spegelns belysning är på. Kopplas Ambient Touch spegel till en väggbrytare behöver denna vara påslagen för att spegeln ska fungera.

### 2.) DIM :

För att ändra ljusstyrkan dimma:

1. Tänd spegeln (tryck på sensor-markering en gång och släpp direkt)
2. Tryck direkt igen och behåll trycket på sensorn en kort stund (Håll ca 2 sekunder) och släpp sedan.
3. Tryck direkt igen och behåll tryck på sensorn och ljusstyrka ändras
4. När önskad ljusmängd uppnåtts släpp sensor

### 3.) Färgtemperatur:

Justera steglöst från 3000K-6000K som upplevs från varmare till kallare ljus genom att:

1. Tänd spegeln (tryck på sensor-markering en gång och släpp direkt)
2. Tryck igen och behåll tryck på sensorn och färgtemperaturen ändras
3. När önskad färgtemperatur uppnåtts släpp sensor

### 4.) Minne:

Spegeln har en inbyggd minnesfunktion som memorerar färg och ljusmängd – detta minne fungerar även efter ett strömbortfall.